


POOL VOLUME FACT SHEET

How to calculate pool volume

In order to calculate how much water your swimming pool holds you will need the following measurements (in metres):

- Length
- Width
- Depth/s

Measuring your pool is simply a matter of determining the maximum width and length of the main body of water. You will also need to know the average depth of the water.



Once you know these measurements you can determine the total volume with the following formula:

$$\text{Length} \times \text{Width} \times \text{Average Depth} \times 1000 = \text{Total Litres}$$

Example 1:

Pool Dimensions:

Length 10 metres

Width 4 metres

Depth 1 metres to 2 metres (average 1.5 metres)

$$\text{Volume} = 10 \times 4 \times 1.5 \times 1000$$

60,000 litres

